


CHUN CHIN WATER GENERATOR INSTRUCTION MANUAL

MODEL NO : CC 1801 1.0

Please read the instructions carefully before use to understand correct method of use. If any unknown or need service, please contact the dealer directly.

Copyright © CHUN-CHIN.All Rights Reserved.



1 - Precautions

Power Supply

- 1.1 Exclusively use 220V / 50Hz AC power socket for power supply.
- 1.2 Power socket loading capacity should more than 5A for unit use only.
- 1.3 The plug should fully inserted into the socket and grounding well.
- 1.4 Switch the unit off and unplug from the power source when cleaning or maintaining it.

When Using

- 1.5 Do not attempt to repair, disassemble, or modify the unit.
- 1.6 Do not carry or use the unit horizontally.
- 1.7 Should abnormal symptoms occur(burning smell, etc.),switch off the unit and unplug it. Contact your dealer or service center for consultation.
- 1.8 Do not put vases or any other objects filled with water on the unit.

Mishandling may result in fatal or serious injuries and unit damages

1 - Precautions


Installation Environment

- 1.9 The unit can operate in a room temperature range of 12~35°C and relative humidity > 40% .
- 1.10 If placed in a closed or less space environment, the unit may result in room temperature rise.
- 1.11 Make sure to leave some space around the unit to ensure good ventilation.
(30cm to left and right sides, 10cm to back side)
- 1.12 Do not use the unit where it may be exposed to direct, rain or near heat-generating devices.
- 1.13 Do not use the unit in places that may be subject to oil, chemicals, peculiar smell, flammable gas leakage or any unhealthy air.


Mishandling may result in fatal or serious injuries and unit damages

2 - Parts and functions

Front & Right side



Back & Left side



3 - Before Use




- 3.1 Connect the power cord and the socket where on the back side of the unit.
- 3.2 Let plug fully inserted into the socket(AC220/50Hz).
- 3.3 Turn on the switch where on the back side of the unit.
- 3.4 Touch screen should be working now, and the left side of the unit (exhaust window) has air flow.
- 3.5 For the first time taking water, the water storage level must be at least high level and the water should be continuously taken and drained out by more than 4 liters.

Mishandling may result in fatal or serious injuries and unit damages

4 - Touch Screen

Home page



-  Generating function is ON
-  UVC lamp is disinfecting
-  Air purifier is working

Environmental Information

Water Storage




Press to start / stop taking water

To setting page

4 - Touch Screen

Setting page



Back to home page

Press 3 seconds to turn ON/off water generator.(default is on)

Press 3 seconds to choose when will air purifier turn on, "On with water generator" or "Auto". In auto mode, it will open automatically when water generating or PM2.5 > 50ug/m3.

To advanced setting.
Enter code : 2000


Press to check filter status.
Sign in code : 3000

Press to view Temp / Humidity / PM2.5 record last 24hrs.

It is water generator product instructions, please be sure to read.

4 - Touch Screen

Advanced Setting page



Press to setting time

Press to increase filters pressure. It might be using when install the new filter.

Press to start / stop taking water

Press to set the longest time for taking water continuously. (10~900 seconds)

Here show the Environmental Information after adjusted.

Press up or down to adjust Environmental Information

Press to reset the value back to original without adjusted.

5 - Use and Maintenance

Notice

5.1 Do not pour juice, tea, or coffee into the water tray to avoid peculiar smell.

5.2 Unplug the unit when not using for an extended period of time.

5.3 After an extended period of time no using, the water in storage tank should be leak out when restart again.

5.5 UVC lamp is inside of the water storage tank, do not look or expose directly for safety.

5.4 Clean the air filter and the funnel at least once a month, and be sure to replace it after cleaning.

For your safety ,please unplug when cleaning or maintaining !

5 - Use and Maintenance

To clean the air filter



Step 0 Unplug the unit.

Step 1 Open the Upper cover.

Step 2 Pull up the air filter as the picture.

Step 3 Clean air filter and put it back.

- * 5mm Non-woven fabric filters can be clean by water rinse or high press air blow.
- 1mm PM2.5 filter should replace new ones.



1. Pull the handle & 2. Pull up the side cover to open it.


To clean funnel

Step 0 Unplug the unit.

Step 1 Open the Side cover.

Step 2 Take out the funnel.

Step 3 Clean funnel and put it back.



For your safety ,please unplug when cleaning or maintaining !

5 - Use and Maintenance

The filter must be replaced at regular intervals to maintain the quality of the water.

Filter and filter's Life

Filter 1 UVC lamp / 1 year.


Filter 2 1 micron PP filter / 6 month

Filter 3 Granular activate Carbon Filter / 6 month

Filter 4 0.0001 micron RO membrane / 3 years

Filter 5 POST carbon filter / 1 year

The above life is the recommended value, depending on the actual situation may have increased or decreased.



1 UVC Lamp is installed inside the water storage tank, do not look or expose directly for safety.

6 - Information

6.1 CODE: CC 1801 1.0

6.2 Power: 450W

6.3 Generating Capacity: 10 / 12 / 16L/per day (at 20/25/30°C RH 80%)

6.4 Storage: 13L

6.5 Dimension: 410(W)x 520(D)x 690(H)mm

6.6 Weight: 54kg (storage is empty level)

6.7 Warranty period: 1 year

Conditions: Any damage caused by misuse of users shall not be covered by the warranty hereof.